Connecting Keyfob

Press 1234 on the control panel. The below message will be displayed.





Press 8 to reach "Setup Users"



Press Yes ✓ **(**Will show you the free User as below)



Press arrow button (⬇ or ⬆) to select the required User



Note: In this example, we selected Master user

Press Omit button ( **)** to select the required User



Press No button (X) it will start learning process



During this learning process you need to power on the keyfob by holding the power button for 4 seconds. once the device is learned will show as below.



Press Menu ( **) three times** on the control panel and then press **Yes** to logoff from your control panel



FAQ:

1. How to arm the alarm panel through Keyfob?

a. Power on the keyfob by holding the power button **(⏻)** for 4 seconds.

b. LED status will show in Blue colour.

c. Press & hold for 2 seconds with arm button **(🔒)**.

d. Then Arm LED status will indicate in Red colour.

2. How to disarm the alarm panel through Keyfob?

a. Power on the keyfob by holding the power button **(⏻)** for 4 seconds.

b. LED status will show in Blue colour.

c. Press & hold for 2 seconds with disarm button **(🔓)**.

d. Then disarm LED status will indicate in Green colour.

3. How to part arm the alarm panel through Keyfob?

a. Power on the keyfob by holding the power button **(⏻)** for 4 seconds.

b. LED status will show in Blue colour.

c. Press & hold for 2 seconds with Part Arm button **(🏠)**.

d. Then part arm LED status will indicate in orange colour.

Note: The SmartKey will power off after 20 seconds of no activity.

4. How to activate panic alarm through keyfob?

a. Power on the keyfob by holding the power button **(⏻)** for 4 seconds.

b. LED status will show in Blue colour.

c. Press and hold disarm **(🔓)** & power **(⏻)** button together for 4 secs.

d. All 3 LED's will start flashing together.

5. How to identify the Alarm Status LED's?

a. Green LED on = Disarmed

b. Orange LED flashing = Part Arming

c. Orange LED on = Part Armed

d. Red LED flashing = Arming

e. Red LED on = Armed

f. All 3 LED's flashing together = Alarm

g. All 3 LED's cycling = Panic Alarm